In-situ zirconia based oxygen analyzers



SYRE

OXYGEN ANALYZER FOR HIGH TEMPERATURE (500 – 1600 °C) BASED ON ZIRCONIUM OXIDE CELL FOR FLUE GASES WITH TWO-WIRE "SMART" TRANSMITTER FOR HAZARDOUS ATMOSPHERES


Zirconium oxide (ZrO2)-based cells use an electrochemical principle to measure the concentration of oxygen in gases. Their operation is based on a few key properties:

- 1. Ionic conductivity: At high temperatures (over 500°C), yttria stabilized ZrO2 (YSZ) exhibits high ionic conductivity for oxygen ions.
- 2. Separation properties: ZrO2 acts as an oxygen ion permeable membrane, separating two chambers: Reference chamber: Exposed to a gas with known oxygen concentration (ambient air) Measuring chamber: Exposed to the gas to be analyzed.
- **3.** Oxygen partial pressure difference: A partial pressure difference of oxygen is created between the two chambers which induces the migration of oxygen ions through the ZrO2 membrane.
- **4.** Electromotive Force Generation (FEM): The migration of oxygen ions generates an electric current proportional to the partial pressure difference of oxygen. This FEM is measured as a useful signal.



- + Direct insertion into the process
- + Probe without gas circulation
- + Fast response time
- + Resistant to high concentration of acids
- + No need of calibration
- + Completely safe
- + Excellent stability
- + Inexpensive
- + HART protocol


Connections






Dimensional drawings

+ Probe



	L (mm)	(*) Pneumatic connections
M = 162 mm	310	[]1/4" NPT
A= 155 mm	500	[]Fittings for 6x4 mm tubing
K = 25 mm	650	[]Fittings for 6.35x4.35 mm tubing
D = 28 mm	900	11 3

+ Transmitter



Description

The reference and measuring gases flow into the two chambers respectively. Oxygen ions migrate through the ZrO2 membrane based on the partial pressure difference when it is at a temperature greater than 500 °C Ion migration generates a FEM proportional to the oxygen concentration in the gas to be analyzed.

Applications

All industrial combustion plants classified as hazardous areas where the process temperature can reach 500° C.

Certifications and Marking



Atex - II 2 (1)G Ex db [ia Ga] IIC T6 Gb, - II 2 (1)D Ex tb [ia Da] IIIC T135°C Db according to EN IEC 60079-0:2018; EN 60079-1:2014; EN 60079-31:2014; IEC 60079-11:2023; EN 60079-31:2014; IEC 60079-11:2023; EN 60079-



Ex db [Ex ia Ga] IIC T6 Gb
- Ex db [Ex ia Da] IIIC T85°C Db
according to IEC 60079-0:2017, IEC 60079-1:2014, IEC
60079-11:2023, IEC 60079-31:2022

Accessories

- Flow meters boxes models 60 and 62
- · AISI 316 stainless steel containers
- Mounting flanges and tubes for probe protection
- 4x1.5 harmored shielded connection cables and 6x4 mm hoses
- Electrical and pneumatic connections can be customized upon request

Technical specification				
Accuracy	Oxygen: In the % range: \pm 0.5% of the theoretical value or 0.5% of O2 (whichever is greater). In the ppm range: 0.5% of FS			
Stability	Within 1% of range			
Response time (90%)	(90%): 1" <" cell, 15" < system			
Technical specification Probe (Analyzer) 4153 "ia"				
Power supply	Not necessary			
Measuring range	Oxygen: 0.0001 ÷ 25% O2 by volume			
Compensation thermocouple	Integrated type B as standard others available			
Storage temperature	-40°C/+80°C			
Operating temperature	Flue gas from 500°÷1600°C , < 200° C for the probe head			
Process connection	1" NPT-M Thread			
Pneumatic connections	Compression fittings for 6x4 mm hose (EDxID)			
Electrical connections	Cable gland for dedicated cable on 3/4" UNI inlet			
Enclosure protection rating	IP66			
Technical specification 9045 Transmitter				
Power supply	2 x 24 Vdc			
User interface	LCD Display & Magnetic Keypad			
Analog outputs	$4 \div 20$ mA max. load 500 ohms. linear on one of the following ranges: $0 \div 5\%$ vol. 02 $0 \div 10\%$ vol. 02 $0 \div 21\%$ vol. 02 $0 \div 25\%$ vol. 02 $0 \div 25\%$ vol. 02			

Display-guided manual, flowmeter box available as an option

-20÷ +45° C; Relative humidity < 90% non-condensing

Declaration of conformity EAC according to TR-CU-004, TR-CU-020, TR-CU-012

FER STRUMENTI S.r.l. reserves the right, without any notice, to make any modifications needed for improving the product.



Other outputs

Calibration

Electrical connections

Storage temperature

Operating temperature

Degree of protection





Hart Protocol Version 6.0

4 x M20x1.5 inlets

-40°C/+80°C

IP65