

GAS PURITY ANALYZER LOW AND ULTRALOW RANGES

MOD. ENOX 12



- Contemporary Measurement up to five gases.
- IR measure based on GFC technology.
- For each gas, availability of two ranges with autoranging.
- Automatic zero calibration. Excellent Span stability.
- Temperature inside the enclosure PID regulated and compensated..
- Barometric pressure compensation.
- Backlit LCD touchscreen display.
- Lack of flow alarm.
- User friendly, menu driven menu
- Ehernet communication with Modbus TCP protocol
- Optional expansion module for analog and digital I/O hard-wired.

Quality (purity) of gases require very accurate measurement of contaminants

The technology that has been chosen and a careful stabilization of the temperature of the analyzer enable the measure with ultra low ranges.

The analyzer that automatically perform zero calibration has no span drift. This means it is not necessary to make recurrent span calibration with expensive test gas mixture.

The analyzer, that has been studied for measuring trace of CO, CO2, CH4, can measure any other gas that has a significant absorption in the IR in the range of sensitivity of the sensor, like HC1.....

APPLICATIONS

Trace impurity in industrial gases – Continuous monitoring of air quality – Air separation measurement PSA – Purity of medical gas – Continuous monitoring of emissions (CEMS) with diluition

FEATURES

Measured gas	CO	ranges (1)	0-10	0-100 ppm
			0-50	0-500 ppm
	CO2		$0-5^{(2)}$	0-100 ppm
			0-50	0-100 ppm
	CH4		0-10	0-100 ppm
			0-50	0-500 ppm

More ranges upon request

Accuracy <1 % F.S

Zero drift none, if automatic zero calibration is on

Response time (90%) < 30 sec. (T90) at 80% F.S.

Noise 20 ppb Gas flow 0.5 - 2 1/min

Serial output Mod bus RTU; RS 485 Analog / digital output 4-20 mA con modulo di espansione

Maximum gas pressure 300 mm H2O Room temperature limits $10 - 30^{\circ}$ C

Power supply 230/115; 50/60Hz

Dimensios (LxHxD) Rack 19", 3U. mm 485x132x450

Weght Kg. 12

FER STRUMENTI srl Italia - 20831 SEREGNO (MI) - Via Ripamonti, 58 tel. +39 0362 231203 - Fax +39 0362 330349

www.fer-strumenti.com fer-strumenti@fer-strumenti.com

⁽¹⁾ at constant temperature

⁽²⁾ enclosure must be purged using with a gas CO2 free.